

WARNING:!!! DO NOT INSTALL CHIME TO DOOR. IF THE RINGING SOUND OF THE CHIME STOPS AS THE DOOR IS CLOSED YOU HAVE THE CHIME INSTALLED TO CLOSE TO THE DOOR. IF YOU OPEN THE DOOR AND CLOSE IMMEDIATELY THE CHIME SHOULD CONTINUE TO RING.

E-Z TONE®


AN ENTRY AND EXIT CHIME

5 YEAR WARRANTY

- FOR SOFTER TONE: REMOVE STRIKER PIN (CH-8) ON END OF SHAFT BY PULLING STRAIGHT OFF AND REPLACE WITH SOFT STRIKER PIN (CH-8A ENCLOSED IN ACCESSORY BAG).
- DOUBLE ACTING DOORS MAY BE CONVERTED TO SINGLE ACTING WITH AN "L" STOP PROVIDED IN ACCESSORY PACKAGE.

SPECIAL FEATURES

1. NO BATTERIES
2. NO ELECTRICITY
3. QUICK INSTALLATION
4. DO IT YOURSELF INSTALLATION
5. NO MAINTENANCE
6. SILENCER TO SHUT SOUND OFF
7. COLORS - BRONZE OR LIGHT GREY
8. EXTRA STRIKER PIN FOR SOFTER TONE




PARTS ARE INSIDE
C H I M E
B O X

SILENCER
SLIDE SILENCER AS INDICATED
TO SHUT CHIME OFF AND ON.

PARTS LIST E-Z TONE CHIME

1/8" drill bit not included

- | | | |
|------------------------------|---|--|
| CH-1 - Shaft and Cup-1, Unit | CH-13 - Sounding Bar Grommet | |
| CH-2 - Metal Disc. | CH-14 - #4 x 3/8" Screw for Lid | |
| CH-3 - Magnet | CH-15 - #8 x 3/4" Truss Head Metal
Screw for Mounting Chime Box
and Metal Disc. | |
| CH-4 - Short Spring | CH-16 - #10-24 x 1/2" Truss Head Bolt | |
| CH-5 - Main Spring "Long" | CH-17 - #10 Lock Washer | CH 11 BRACKET ONLY NEEDED FOR
INSWING TYPE DOORS |
| CH-6 - #6 Plain Washer | CH-18 - #10 Plain Washer | |
| CH-7 - "E" Spring | CH-19 - #10-24 Keps Nut | SLOTTED SCREWS CH15 ARE INCLUDED BUT
IF YOU HAVE THEM 1/2" size #8
HEX HEAD SCREWS WILL MAKE THIS
INSTALLATION MUCH EASIER. |
| CH-8 - Striker Pin | CH-20 - 1/8" Drill Bit | |
| CH-8A - Soft Striker Pin | CH-21 - Silencer | |
| CH-9 - Chime Box Lid | CH-22 - Grommet Pin | |
| CH-10 - Chime Box | CH-23 - Retaining Ring | |
| CH-11 - Bracket | CH-24 - Door Stop to change Double acting
doors to single acting | |
| CH-12 - Sounding Bar | | |



FIVE YEAR LIMITED WARRANTY

This product is warranted, to the original purchaser, to be free from defects in material and workmanship, under normal use, for a period of five years from purchase date. If the product becomes defective during this warranty period, it will be replaced or repaired with no charge for parts or labor. The purchaser shall bear the shipping and packaging costs of \$5.00. This warranty will not apply if the product has been misused, altered or abused. For warranty service, return product with proof of purchase and \$5.00 to: E-Z TONE WARRANTY, 6255 Gram Suite 212, Dallas, TX 75214 or call toll free: 1-800-398-5127.

L. D. PIERCE
1-800-398-5127
P.O. BOX 141324
DALLAS, TX 75214